


California Bander Instructions



1. Insert the clip into the notch on the tool.




2. Firmly grasp the scrotal sac.



3. Pull until the free stretch is gone.



4. Pull around. (Don't relax the tension!)



5. Pull through the clip into the right hand corner.



6. Tip to release the tool. You are DONE!